WASHER/DRYER CONTROL PANEL PARTS

For Model: WET3300SQ0
(Designer White)

WASHER/DRYER
LAUNDRY SYSTEM



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
		Installation Instructions
	W10118289	English
	8578179	English
	W10118304	Sheet, Cycle Feature
	W10113806	Wire Diagram
	W10118487	Energy Guide
2	3390688	Spacer Foam Pad (2)
3	8528583	Bracket, Control (Includes Illus. 2)
4	W10113761	Timer, Washer
5	W10121648	Jumper Wire (Timer−Buzzer)
6	8566018	Dial, (Washer)
7	8566022	Knob, Timer (Washer)
8	8565944	Knob, Control (2)
9	8521965	Gasket, Console
10	3389464	End, Cap (LH)
11	8566061	Knob, Timer (Dryer)
12	3400808	Screw, 10−32 x 5/16
13	W10112533	Switch, Pressure
14	W10114118	Switch, Temperature
15	90767	Screw, 8−18 x 3/8
16	3404233	Switch, Push−To−Start
17	8566073	Knob, Push−To−Start
18	694419	Buzzer, Mini
19	W10113804	Timer, Dryer
20		Panel, Control
	W10114898	White
21	3389453	Bracket, Hinge (2)
22		End Cap (RH)
	3389456	White
23	W10119331	Harness − Dryer
23B	2154470	Receptacle,
23C	3395683	Connector (Motor−Dryer)
24	3390604	Clamp, Harness
25	3390422	Clip, Harness (2)
26	8536939	Spring, Clip Knob
27	2219077	Clip, Harness

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER FRONT PANEL AND DOOR PARTS

For Model: WET3300SQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	3389249	Nut, Push (4)
2	3391901	Switch, Door
3	98234	Clip, Ground
4	3392547	Panel, Front
5	3390735	Seal, Door
6	3392563	Door, Rear
7	3387872	Door, Front
8	3388229	Retainer, Toe Panel (2)
9	3387242	Bearing & Seal
10	694091	Screw, 8−18 x 3/8
11	696144	Strike, Panel
12	697773	Screw, Door Switch Mounting (2)
13	3393008	Screw, 10−16 x 1/2
14	3392538	Catch, Door
15	W10095180	Handle, Door
16	3390902	Clip, Door Hinge (2)
17	3388958	Panel, Toe
18	342055	Screw, 8−18 x 1/2
19	3389247	Hinge & Pin, Door (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER CABINET AND MOTOR PARTS

For Model: WET3300SQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER CABINET AND MOTOR PARTS

For Model: WET3300SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	660658	Clamp, Motor Mounting (2)
2	8538266	Motor, Main Drive (60 Hz.)
3	3398948	Wire, Jumper
4	3394881	Switch, Broken Belt
5	3388858	Bracket, Motor
6	3389847	Panel, Rear
7	343641	Screw, 10−16 x 1/2
8	3387673	Cover, Terminal Block
9	8533974	Screw, Ground (10−32 x 1/2)
10	3389264	Panel, Side (L.H.)
	3389256	Panel, Side (R.H.)
11	8066120	Lever Snap Switch
12	279318	Terminal, Tinned & Brass (3)
13	279393	Screw−Kit (For Terminal Block)
14	3394081	Wire, Broken Belt Switch
15	3389231	Clip, Front Panel (2)
16	98234	Clip, Ground
17	3391639	Bracket, Bulkhead
18	690997	Washer, Thrust
19	690997	Tri−Ring
20	3387610	Belt, Drive
21	3391087	Pulley, Motor (60 Hz.)
22	3389332	Bracket, Idler
24	3390026	Base, Dryer
25	3387374	Spring, Idler
26	3389683	Cove, Transition Panel (Black)
27	3389272	Panel, Transition
28	3389537	Top, Dryer
29	3390722	Shield−Console To Drum
30	3389682	Spacer (2)
31	3393722	Bracket, Terminal Block
32	3389431	Bumper, Lid Stop
33	693304	Screw & Washer
34	3387485	Screw, 10−16 x 5/8
35	98129	Screw, 6−20 x 1−1/16
36	3397659	Block, Terminal
37	3390631	Screw, 10−16 x 3/8
38	3389420	Bolt, Shoulder
39	3388672	Pulley, Idler
40	3394743	Pin, Roll
41	692400	Nut, Push−In

DRYER BULKHEAD PARTS

For Model: WET3300SQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER BULKHEAD PARTS

For Model: WET3300SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, Roller
2	90767	Screw, 8−18 x 3/8
3	343641	Screw, 10−16 x 1/2
4	3394984	Door, Lint Screen
5	697354	Air Duct Assembly
6	697813	Seal, Outlet Housing
7	3391906	Seal, Lint Duct
8	3934666	Nut (2)
9	8066086	Drum Hole Plug
10	3389449	Baffle, Drum (3)
11	8563748	Pipe, Exhaust
12	3390647	Screw, 8−18 x 1/2
13	3391685	Seal, Transition Duct To Lint Duct
14	3387749	Element, Heater
15	279457	Wire Kit (For Heater Element Wiring Harness Repair)
16	W10001120	Nut, Hex (2)
17	3387809	Bulkhead, Rear
18	3387459	Washer, Support
19	8575325	Shaft, L.H. Thread
20	690997	Tri− Ring
21	8536973	Support, Roller
22	3357011	Screw, 10−16 x 1/2
23	3394985	Housing, Outlet
24	695240	Screw, 8−18 x 1/2
25	3389448	Assembly, Drum
26	W10109200	Screw, 11−16 x 3/4
27	697694	Seal, Drum
28	3387230	Screw, 10−16 x 13/16
29	697557	Bulkhead, Front
30	8299979	Grille, Front
31	697770	Seal, Cover Plate
32	3389644	Screen, Lint
33	8566209	Seal, Transition Duct
34	3403607	Thermal−Limiter
35	3390935	Clip, Duct Locator
36	3389647	Bracket, Heater Mounting
37	697772	Wheel, Blower
38	3389445	Duct, Transition (Includes Illus. No.33)
39	697366	Plate, Blower
40	3394986	Spring, Lint Screen Door
41	3390291	Fixed, Thermostat
42	3387134	Thermostat, Internal−Bias
43	3977394	Thermal−Cutoff (Includes Illus. 41.)
44	8544363	Housing, Blower
45	3388909	Lint Duct Assembly (Includes Illus. 7 & 13)
46	697715	Box, Heater

DRYER SUPPORT AND WASHER HARNESS PARTS

For Model: WET3300SQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER SUPPORT AND WASHER HARNESS PARTS

For Model: WET3300SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	W10114956	Harness − Washer
1A	3350130	Plug, 3 Way
1B	3347243	Connector, 5 Way
1C	352089	Block, Disconnect − Timer
1D	3350211	Receptacle, 3 Way
1E	62505	Block, Disconnect
2	3388851	Channel Assembly (Left Hand Side)
3	3388850	Channel Assembly (Right Hand Side)
4	3390609	Shield, Harness
5	8545438	Hose, Pressure Switch
6	8281256	Clip, Harness
7	343641	Screw, 10−16 x 1/2
8	685463	Kit, Grounding
9	8533971	Screw
10	685449	Wire
11	63523	Protector, Harness
12	22965	Strap, Grounding
13	3400300	Bolt, 5/16−18 x 1/2 (4)
14	3393930	Nut, Hex (4)
15	3394350	Shield, Front
16	3390336	Shield, Thermostat
17	3393008	Screw, 10−16 x 1/2
18	3391249	Clip, Harness (2)
19	3354925	Connector, H−Pod
20	3360056	Connector, Pressure Switch
21		Terminal,
	94613	Male
	94614	Female

WASHER TOP AND LID PARTS

For Model: WET3300SQ0
(Designer White)



WASHER TOP AND LID PARTS

For Model: WET3300SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1		Lid
	3351652	White
2	9724509	Bumper, Lid (2)
3	3351355	Screw And Washer
4	343641	Screw, 10−16 x 1/2
5	692400	Nut, Push−In (2)
6	3349817	Top
7	357572	Clip, Grounding
8	3354020	Bracket Mounting
9	3350152	Lid Retainer
10	3350828	Clip
11	21258	Hinge, Bearing (2)
12	3356311	Screw And Washer
13	358684	Strike, Lid
14	3350101	Hinge, R.H.
15	3350102	Hinge, L.H.
16	3362952	Dispenser, Bleach
17	3355458	Switch, Lid
18	90016	Clip, Wire (4)
19	3390481	Locator, Top

WASHER CABINET PARTS

For Model: WET3300SQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WASHER CABINET PARTS

For Model: WET3300SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	3349770	Clip, Spring Top (2)
2	3349768	Bracket, Vacuum
3	62863	Screw, Mixing Valve Mounting
4	3350013	Foam
5	3979349	Valve, Water Mixing
6	370451	Clamp, Hose
7	8521954	Hose, Water Inlet (Vacuum Break To Mixing Valve)
8	3349455	Panel, Side (2) (Same Panel Used On Left And Right Side)
9	3350745	Brace, Front Panel
10	3353841	Hose, Drain
11	9740848	Screw, 8−18 x 1/2
12	660975	Plug, Top To Cabinet (2)
13	8557915	Connector, Hose
14	356138	Clamp, Hose
15	3349673	Bracket, Valve
16	387606	Thermister, Inlet
17	371503	Clamp, Hose
18	3350145	Shield, Lid Switch
19	3402724	Base, Cabinet
20	3388857	Bracket, Base
21	371507	Clamp, Hose
22	3394083	Clip, Front Panel (2)
23	3349311	Link, Leveling
24	359364	Clip, Leveling Mechanism (2)
25	98234	Clip, Ground
26	345670	Lock, Top (2)
27	3349499	Panel, Front
28	352292	Nut, Push−In (2)
29	358594	Foot, Rear (2)
30	3350144	Bracket, Lid Switch
31	3393930	Nut, Hex (2)
32	352292	Nut, Push−In (2)
33	3400300	Screw, 5/16−18 x 1/2
34	389102	Foot, Front (2)
35	3400917	Nut, Jam (2)
36	3349493	Panel, Rear (Washer)
37	343641	Screw, 10−16 x 1/2
38	3349697	Rail, Back Top
39	3350135	Spring, Lever Bracket
40	3390608	Shield, Corner Right Rear
41	303294	Edge Protector

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Model: WET3300SQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	388951	Brake And Drive Tube (Complete) (Refer To Page 18 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3951311	Clutch (Complete)
6	3951308	Band And Lining (Includes Illus. 7 & 8)
7	3946792	Spring & Damper Assembly
8	62646	Cap, Clutch Spring (2)
9	8532118	Gearcase (Complete)(Refer To Page 17 For Further Breakdown)

Illus. No.	Part No.	DESCRIPTION
10	3357334	Screw, 5/16−24 x 5/8
11	62611	Plate, Motor Mount To Gearcase
13	3364003	Coupling, Motor & Isolating
14	661600	Motor, Main Drive
15	8572717	Capacitor, Motor Start
16	8316060	Shield, Motor
17	62863	Screw, 10−16 x 3/8
18	3363892	Pump, Complete
19	8546127	Retainer, Pump
20	62850	Switch, Main Drive Motor
21	62691	Grommet, Motor (4)
22	3349637	Retainer, Motor (2)
23	3362089	Shield, Tub To Motor
24	3387485	Screw, 10−16 x 5/8
25	3949496	Clamp, Capacitor
26	3355454	Clip, Anti−Rattle

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Model: WET3300SQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	343641	Screw, Bracket Mounting (10−16 x 1/2)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring, Suspension (3)
4	8575214	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
7	3400076	Screw, 10−32 x 5/8
9	3350506	Retainer, Hose
10	63134	Ring, Sound Deadening
11	63806	Retainer, Suspension Spring
12	3400501	Screw, 5/16−18 x 1 3/32
13	8546455	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	388492	Spring, Counterweight
16	62568	Pad, Plate
17	3946509	Plate, Suspension (Includes Illus. 16)
18	3363660	Pad, Base
19	3349343	Base Assembly (Includes Illus. 11 & 18)
21	3349749	Restrainer, Base
22	3349340	Washer (2)
23	8577376	Seal, Centerpost
24	285203	Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)

AGITATOR, BASKET AND TUB PARTS

For Model: WET3300SQ0
(Designer White)



AGITATOR, BASKET AND TUB PARTS

For Model: WET3300SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	3350834	Dispenser
2	3947410	Cam Driven
3	3366877	Dog, Agitator (4)
4	358237	Screw & Washer
5	387094	Cap, Barrier
6	3349610	Mover, Agitator Clutch
7	3351014	Spacer, Thrust
8	3349578	Agitator
9	8528150	Tub Ring
10	3976308	Gasket, Tub Ring
11	3979385	Basket
12	21366	Nut, Spanner
13	8519788	Ring, Balance
14	3349292	Tub
15	3951449	Hose & Clamp Assembly
16	389140	Block, Drive
17	383727	Gasket, Centerpost
18	3348855	Seal, Inner Cap
19	3363366	Clamp, Hose (2)
20	3949550	Washer
21	3349743	Agitator (Complete)

GEARCASE PARTS

For Model: WET3300SQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	8532118	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring (2)
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 & 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 & 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust (Includes 18)
18	85529	Ball, Bearing (Includes 17)
19	389230	Bottom and Pinion, Gearcase
20	3949116	Block Tab, Terminal
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover Mounting (8) (10−24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE AND DRIVE TUBE PARTS

For Model: WET3300SQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	388951	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	356427	Seal, Drive Tube
4	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
5	64035	Ring, Retaining
6	64232	Shoe, Brake (2)
7	62703	"T" Bearing, Spin Tube
8	3353956	Cap, Brake Spring (2)
9	62647	Spring, Brake
10	3355360	Sleeve, Brake Spring
11	661516	Cam, Brake Release
12	63022	Sleeve, Cam
13	64194	Driver, Brake Cam
14	90368	Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED

285208	Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WATER SYSTEM PARTS

For Model: WET3300SQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	285321	Sleeve Kit, Plastic Drain Hose (Contains 2 Sleeves)
2	65349	Clamp, Hose (2)
3	16272	Connector, Straight
4	285320	Siphon Break Kit (Not Included)
5	661575	Hose, Corrugated Plastic Drain (5 1/2 Ft.)
	W10108350	Hose, Corrugated Plastic Drain (6 1/2 Ft.) (For FSOU & Twin−Twin)
	661577	Hose, Corrugated Plastic Drain (10 Ft.) (Not Included)
6	8577378	U−Bend
7	3357331	Clamp, Hose
8	356739	Connector, Hose
9	3354858	Hose, Inlet (2)
10	285442	Connector Kit, Plastic Drain Hose

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Model: WET3300SQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	3356714	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose
3	356138	Clamp, Hose
5	3357331	Clamp, Hose (Upper Drain)

OPTIONAL PARTS (NOT INCLUDED)

For Model: WET3300SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	4392899	Biscuit
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350938	Primer, Gray
	350930	White
	4392901	Biscuit
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	4392900	Biscuit (Uncut)
		OIL
	350572	Oil, Gearcase (16 Oz.)
		LUBRICANT
	285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)
		SEALER
	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
		ACCESSORIES
	279823	Side Exhaust Kit